


# What You should know about the Silicon

*Friendly Advice:*

- Learning about how things work will save time, increase efficiency, and earn **Glory and Praise**
- Your SciCo is **NOT** an expert, so don't let them waste too much time theorizing, page a real expert

# Introduction



- L00 (1 layer)
  - $R = 1.35\text{-}1.65 \text{ cm}$
  - 13824 channels
- SVX (5 layers)
  - $R = 2.5\text{-}10.6 \text{ cm}$
  - 405504 channels
- ISL (2 layers)
  - $R = 20\text{-}28 \text{ cm}$
  - 303104 channels

Total: 722432 chnls

- Share same DAQ architecture

# Introduction

The silicon detector can be permanently damaged by:

- A. Powering (STDBY or ON) without adequate cooling
- B. Large charge deposits (from unstable beam) while ON
- C. Incorrectly powering

We minimize chances of incurring such damage by:

- A. Employing PLCs to monitor status of silicon cooling
- B. Employing various loss monitors to determine beam stability
- C. Employing “clever” monitoring/control software

And as a final mitigating factor:


We rely on YOU to help quickly spot potential dangers.

# Monitoring

There is information available from a variety of places:

A. Silicon Cooling... overall status from


- "Process Systems Alarms" summary
- Sono-Alarms



# Monitoring

## B. Beam losses from ACNET


- Losses (LOSTP, LOSTPB, etc...)
- SVXRAD plots



# Monitoring


## C. Power status

- Silicon Power Supply Control GUI
- HV Summary and Global Alarms



# Monitoring

IF **Silicon Cooling** .and.



- Cooling in good shape

Obey TevMon, ACNET Losses, SI\_TEST1 and SI\_TEST2 plots (put in e-log)

- Beam is stable

IF **L00** .and. **SVX** .and. **ISL** on Global Alarms Sum'ry


- Powered wedges OK

# THOU SHALT NOT OPERATE SILICON

## WITH BEAM UNLESS

- The electron lens is on
  - Monitor w/ ACNET variable T:L1COLI
- There is “normal” DC beam in the machine
  - Monitor w/ ACNET variables , C:B0PBSM and C:B0ABSM gated on abort gaps
  - No sudden unexplained longitudinal growth of beam (T:SBDMS)
  - No sudden unexplained change in luminosity ( $\Delta C:B0ILUM > 10\%$ )
- The Tevatron Radio Frequency (RF) system is stable
  - Monitor w/ ACNET variables , T:RFSUM and T:RFSUMA
- The Tevatron losses are minimal and stable
  - LOSTP, LOSTPB < 20 kHz,  $\Delta$ LOSTP,  $\Delta$ LOSTPB < 2.5 kHz/hour, No spikes > 25 kHz
- The Beams Division is not doing any “harmful” parasitic studies
  - When in doubt, page Silicon
- Silicon stays in STANDBY between stores unless Beam warrants “OFF”
  - Avoid excessive power cycling & associated thermal stresses
  - Hints that STANDBY safer than ON, but that STANDBY may not be totally safe
- **No silicon use in DAQ/trigger tests without permission from silicon pager.**

# TevMon Beam Conditions Monitor



- Monitors ACNET variables for silicon safety
- One cell for each criterion in ACNET checks
  - plus one cell for overall decision on SVX Danger!
- If SVX Danger cell turns Red, follow ACNET incident rules (call MCR, page silicon)
- Before turning on silicon after scraping, check TevMon and then get expert's permission to turn on.
- TevMon is an essential process
  - check the time stamp to make sure that it is updating

# Radiation Problems ("EEEEEEEEE")


For SVXRAD plots, follow RADMon run rules.

**On alarm, page Si:218.8227 and RadCo: 266.2713**

IF any of the silicon specific ACNET variables are out of range (see monitoring ACE instructions) or otherwise indicate unstable beam conditions

Ask SciCo to notify MCR crew chief and find out why

- Meanwhile page silicon: 218.8227
- If you fear for safety of silicon: use HV Summary button to bring to STDBY (will take a few minutes)



# Quick SI -PS-GUI Tutorial


Labels: DBbWw-Ll (e.g. SB2W3-L3 = SVX brl-2 wdg-3 lyr-3)

D: S=SVX, I=ISL, L=L00

B: barrel number (0-5)

W: wedge number (0-11)

L: layer number (0-4)



Wedge by wedge status:

**yellow** = STBY    **green** = ON

**red** = OFF s/b ON    **black** = OFF s/b OFF


Also, can select particular  
Wedge by clicking on appropriate  
“pie piece”; **blue** = selected

Only use GUI  
when coached  
by expert!  
(Use iFix for  
Most actions.)

# Cooling Problems ("OU-OO" or "EEE")


IF      **Silicon  
Cooling**      .or.      **sono-alarms  
(LOUD)**

- Page 218.8227 (main pgr)
- Page 218.8626 (interlock pgr)
- Check GUI message window...



IF persistent (1 or 2 ok)  
**"ALERT" .or. "ILLEGAL"**  
messages (check time stamp):

Hit the Silicon Rack Power  
Crash Button



# Si Power Problems/Trips ("Tweet")

IF **L00** .or. **SVX** .or. **ISL** on Global Alarms Sum'ry


- Sometimes will clear themselves... otherwise:
- Go to HALT State, Page 218.8227
- Expert will either take care of it themselves, or, they may coach the Monitoring Ace through recovery

IF SI PS GUI stops Updating:

- Occasionally (1-2/shift) check that "Update" is counting down
- Be patient, gets "stuck" on "1" for 5-10s sometimes
- If recently changed voltage state (e.g. turned to STBY or ON), wait ~5 minutes and check again
- If really "stuck", follow directions to restart  
(they're taped above the GUI screen)

# Quick iMon Tutorial

- Tracks currents for experts by color:
  - GREEN = Normal
  - YELLOW = Warning
  - PINK = Alert
  - RED = Trip
  - BLACK = Not Powered
- *We need your help monitoring these currents, which may signal imminent danger to the silicon.*




Instructions for restarting iMon are above the silicon terminal

# Ace's IMon Responsibilities

- Aces should respond to *any* IMon cells that have turned **pink during data taking only.**
  - When data taking begins, Ace needs to unmark all IMon cells.
  - If cell is **pink** during data taking, ACE should:
    - Note the ladder and current which has latched.
    - Unmark cell.
      - If it turns **green**, document in e-log, nothing more.
      - If it remains **pink**, page silicon, use IMon to plot current history, click “Print”, and paste plot in e-log.
    - Talk to CO, see if latched cell was correlated with data errors in SVXMon Cell Id Status plots.
      - If so, perform HRR if not performed automatically already.


# Quick SVXMon Tutorial

- SVXMon used for automatic checking of silicon data quality ***and to intervene w/ run control in certain cases.***
  - SVXMon generates auto-HRR in case of Cell Id errors (plot from SVXMon slides)
    - Max. rate every 2.5 mins.
  - Monitor history of automatic HRR with SvxErrorLogger
  - **In case of constant HRR from SVXMon, page silicon**
  - For unbiased silicon pop-up error windows
    - Follow instructions
    - Page Silicon



# Silicon from the DAQ Perspective

- Silicon is different
  - 17 crates, but **ONE SRC** which talks to TSI
    - All **BUSY**, **DONE**, and **ERROR** timeouts come from it *though problem may be elsewhere*
  - Due to SVT, Si reads out to VRBs after L1A (not L2A)
    - VRBs are crucial
    - **L1DONE** signal to TS indicating data transferred to VRB
  - CPUs play role only in initialization and monitoring
  - b0svx\*\* crates shared with EVB



# Silicon DAQ configuration

- Partitioning
  - **CrateSet**: All Vrb crates included, dropping Fib crates is OK.
  - Choose an **SvxSet** (e.g. **SVX\_NO\_PEDS**) (Si run dependent parameters)
  - TS settings to play nice with the SRC
    - **IgnoreBusy** = **false** else the TS ignores the VRBs.
    - **UseSrc** = **true** else the TS ignores L1 DONE
- Initialization
  - Fib crates also initialize ladders, which sometimes do not “readback” the init parameters correctly

b0fi b02: Error Initializing HDI Slot 18 Chan 6: SB2W7

Re-issue COLDSTART for that Fib crate only, look for Trips. **Do not power cycle the crate, it will not help.** If persistent, page Si pager, who will either mask off or remove the ladder
  - **Only when a crate does not respond to RC signals does it justify rebooting it.**

# Silicon DAQ Runtime Errors

- Run Time Errors: **Hal t** -Recover -Run is first line of defense. If anything persists, page Si pager
  - HALT → all Si crates query all boards and find potential problems  
**Si l i con Ti meout: BUSY- Slots: 10: fa00 12: fa20...**
  - Done T0: Data did not get sent to the Vrb. Very rare, usually means a VRB is bad.
  - L1 Done T0: TS has lost count of how many free buffers in Si Chips. Modulo fixed TS firmware, exceedingly rare
  - Error: Currently not pulled by SRC, but may be soon to prevent Silicon damage from high current/high occupancy states
  - Busy T0: Means VRB has no more space for events. Exceedingly common , as **EVB** stops when any data corruption is detected anywhere (normally **NOT** in a Silicon crate) and the Silicon VRBs fill up first. Find data corruption and page responsible group
  - Done T0 from **TRIGGER\_SCALERS\_00 Rate too high**: L1A rate too high to safely operate silicon. Usually trigger table is corrupt or there's a hot trigger. Page Trigger, look at TrigMon


# Web Documentation

www-cdfonline/mcs/mondoc.html

Silicon

The screenshot shows a web page titled "CDF Hardware Monitoring Documentation". At the top, there is a navigation bar with links to "Home Page", "CDF Home", and "Site Map". Below the navigation bar is a table with five columns: "CDF iFix Show", "Controls (MCS)", "ACNET - Beam", "Utilities + Safety", and "DAQ, Misc". Under "CDF iFix Show", there are links to "Tutorial", "Homepage", "Instructions to Shift", "Recovery Procedure", and "Access Security". Under "Controls (MCS)", there is a link to "Web-Server Pics". Under "ACNET - Beam", there is a link to "Tutorial Shat Setup - RadMon". Under "Utilities + Safety", there is a link to "Monitoring Ace Page". Under "DAQ, Misc", there are links to "DAQ Ace Info" and "Operations page". Below the table, there is a legend: "READY" (green), "Preliminary" (yellow), and "Not yet available" (grey). A note says: "In case of problems with systems that do not yet have recovery procedure available, Please click here for Expert call-in phone lists." Below this is another table with five columns: "COT HV", "MUONs - HV", "CES-CCR-CPR", "CEM,CWHA,GAM", and "Trigger Inhibit". The "COT HV" row contains a link to "Instructions to Shift". The "MUONs - HV" row contains a link to "Instructions to Shift Tripl Recovery". The "CES-CCR-CPR" row contains a link to "Instruction to Shift". The "CEM,CWHA,GAM" row contains a link to "Tutorial Instructions to Shift Recovery Procedure". The "Trigger Inhibit" row contains a link to "Design Notes". Below this is a second table with five columns: "SVX/SL,L00", "CSX, CSP", "TDF", "PEM-PHA-PSH", and "Idle DB". The "SVX/SL,L00" row contains links to "Instructions to Shift", "Coating PS Recovery Procedures", and "Radiation Mon.". The "CSX, CSP" row contains a link to "Shift Instructions". The "TDF" row contains a link to "Not Available". The "PEM-PHA-PSH" row contains a link to "Not Available". The "Idle DB" row contains a link to "Not Available". Below this is a third table with five columns: "MNP, RPS", "BSC", "CLC", "PTM plug temp", and "PSM power sup". The "MNP, RPS" row contains a link to "Instructions to Shift". The "BSC" row contains a link to "Instruction\_Recover". The "CLC" row contains a link to "See the Alarm Help Section on the VoltMan page for PSM trips.". The "PTM plug temp" row contains a link to "Not Available". The "PSM power sup" row contains a link to "Not Available". Below this is a fourth table with five columns: "PC BACKUP", "XXX", "Template", "XXX", and "XXX". The "PC BACKUP" row contains links to "Procedure", "What items", and "Other info". The "XXX" row contains a link to "Not Available". The "Template" row contains a link to "Tutorial Instructions to Shift Recovery Procedure". The "XXX" row contains a link to "Not Available". The final "XXX" row contains a link to "Not Available".

[www-cdf.fnal.gov/internal/silicon/scc.html](http://www-cdf.fnal.gov/internal/silicon/scc.html)



# [www-cdfonline.fnal.gov/~svxii/runii/ace\\_mon.html](http://www-cdfonline.fnal.gov/~svxii/runii/ace_mon.html)

## CDF RUN II COMMISSIONING

### CDF Monitoring Ace Silicon Instructions

As a monitoring ace, your silicon responsibilities are to:

1. MONITOR BEAM conditions using TeVMon and ACNET as follows:

- Check SVX DANGER status in TeVMon:
  - If SVX DANGER is **PINK** page silicon (218-8227)
  - If SVX DANGER is **RED** bring HV to standby and page silicon (218-8227)
- At least once per hour, make the following ACNET plots *and* place them in the e-log:
  - Shift Losses (C:LOSTP, C:LOSTPB, C:B0PLOS, C:B0ALOS)
  - SI-Test1 (T:L1COLI, T:RFSUM, C:B0PBSM, C:B0RAT4)
  - SI-Test2 (T:SBDMS, T:RFSUMA, C:B0ABSM, C:B0ILUM)
- At least once per hour, check that the following criteria are satisfied:
  - The electron lens is ON ( $L1COLI > 0$ ).
  - Losses are acceptable ( $LOSTP, LOSTPB < 20.0$  kHz).
  - Losses are not growing rapidly ( $\Delta LOSTP, \Delta LOSTPB < 2.5$  kHz/hour).
  - Losses are stable (NO spikes  $> 25$  kHz).
  - There is no sudden increase/decrease in luminosity ( $\Delta B0ILUM < 10\%$ ).
  - RP is stable ( $\Delta RFSUM, \Delta RFSUMA < 0.25$ /min).If ANY of these criteria are even *momentarily* not satisfied, page silicon (218-8227).

2. CONTACT SILICON expert when anti-protons are being loaded.

- Page 218-8227 (main silicon pager).
- Alert silicon expert that store is in.
- Report SVX DANGER status in TeVMon to silicon expert:
  - If SVX DANGER is **GREEN** silicon HV can be ramped up at silicon expert's discretion.
  - If SVX DANGER is **RED** or **PINK** silicon can not be included. Have SciCo call MCR to address problem.
- If silicon expert decides beam conditions are ok, they will instruct you to ramp up HV.

3. REACT to loud noises and/or non-green color from IPix.

- Be familiar with and follow the following specific recovery procedures:
  - [Power supply alarms/trip](#)
  - [Cooling problems/interlock trip](#)
  - [Loss of HV monitoring](#)
  - [Loss of alarm monitoring](#)
  - ["Alarm: Heartbeat"](#)
  - ...  
...  
...

# [www-cdfonline/~svxii/runii/svx\\_recover.htm](http://www-cdfonline/~svxii/runii/svx_recover.htm)

## CDF RUN II COMMISSIONING

### Recovery Procedures for Silicon Cooling/Power

*Note: in what follows, "Alarm List" refers to the iFix page that pops up when the "D" button on the Global Alarms page is clicked. Clicking the box that says "SVX," "ISL," or "L00" pops up something called an iFix Alarm Summary Object, which is a lot like an alarm list, except that it sucks.*

#### 1. POWER SUPPLY TRIP

*Symptom:* A box goes red and tweets. IN ADDITION, the bars and status box on the HV summary page go red.

*What should you do?* Check the Alarm List. From there you will be able to read what ladder has tripped (B1W2 L3, for a random example). Page 218.8227 armed with this information and the expert will help you recover. *Note: if, after recovery, the iFix alarms haven't cleared, try clicking "Reset Traps in CARN" on the PZ GUI.*

#### 2. COOLING PROBLEMS/INTERLOCK TRIP

*Symptom:* These are signaled by either of the following:

1. The "SILICON Cooling" box on the iFix "Process Systems ALARMS" page goes red and LOUD sirens blare (can only be silenced by the cryo techs)
2. The silicon sono-alarms (located on the patch panel in rack JRR04B) emit a loud, sustained, annoying beep (can be silenced by flipping the switch beneath them)

*What should you do?* The VERY FIRST THING YOU SHOULD DO is check the silicon PS GUI. If it is stuck (i.e. not counting down, see below), or if it is spewing out LOTS of messages like "ALERT" or "ILLEGAL," then hit the **Silicon Rack Power Crash Button** located underneath the sono-alarms.

In any event, page 218.8227 and the [on-call cooling/interlock expert](#) at 218.8626. They will help you recover. At the end of it all, make sure the sono-alarm switches are returned to "NOT SILENCED" and the cryo techs have unsilenced the Process Systems alarms.

*Note: A non-severe cooling problem can be signalled by a red (or yellow) tweetey iFix alarm that is not accompanied by a sono-alarm or a Process Systems alarm. These are rare enough that we would like you to page the [on-call cooling/interlock expert](#) at 218.8626 so we can understand the problem.*

#### 3. LOSS OF HV MONITORING

*Symptom:* ALL THREE silicon boxes (SVX/ISL/L00) go red and tweet at the same time. The Alarm List shows "GUI/iFix communication NOT OK." After some amount of time (could be seconds, could be minutes), the three silicon heartbeat boxes on the HV summary page go purple.

*What should you do?* Check the silicon PS GUI and see if it is updating (look in the upper left corner of the window where it says "next update." It should count down from 7, stop for a few seconds at 1, then start counting down again). If it seems to be stuck,

1. Wait a little longer, like 30 seconds. If you have just recently turned a bunch of power supplies on or off, wait even longer, like 5 minutes.
2. If it's still stuck, restart the GUI by following [these instructions](#) (also posted on the GUI PC -- and they ought to be identical).
3. If the GUI does not restart gracefully, page the GUI expert at 266.0555.
4. If the GUI restarted OK, the alarms should disappear. If they remain, or if the GUI never seemed to be stuck in the first place, page the [on-call cooling/interlock expert](#) at 218.8626. She will either take care of it or tell you how to take care of it.

#### 4. LOSS OF ALARM MONITORING

Send: Done (0.391 secs)

-3-

# Useful DAQ Hints for ACEs

[www-cdf.fnal.gov/internal/silicon/silicon\\_commission/daq/sidaq\\_sop.html](http://www-cdf.fnal.gov/internal/silicon/silicon_commission/daq/sidaq_sop.html)

## CDF RUN II Silicon

### Silicon DAQ Standard Operating Procedures

#### Introduction

Here is the list of Standard Operating Procedures for running and maintaining the Silicon DAQ. They are geared toward Aces and Non-Expert Silicon people. In all cases you should make a note in the elog with run number and a snippet of the problem.

- [Unresponsive Fib \(b0fibXX\) or Vrb \(b0svxXX\) crate](#)
- [Failed Warm/Cold Start from Fib](#)
- [Failed Warm/Cold Start from Vrb](#)
- ["No response from the Fib" when powering up Silicon wedges](#)
- [BUSY Timeout from b0svx02](#)
- [DONE Timeout from b0svx02](#)
- [High Rate of RF errors](#)
- [How to Decode a Fib Id](#)
- [How to Mask Init Readback on an HDI](#)
- [How to Chop a Chip Chain](#)
- [How to Download Sequences](#)
- [Power Outage](#)

# **Who to Call?**

Ran Out of time!

[http://www-cdf/internal/silicon/silicon\\_commission/pager.html](http://www-cdf/internal/silicon/silicon_commission/pager.html)  
(posted in the control room too)

## Conclusion

Your main responsibility to silicon is to help keep it safe.

When in doubt, page 218.8227...  
if no response, turn it to STANDBY  
(or OFF if there's a cooling problem).