

# ACNET and Shot Setup

"JJ" Schmidt

Ace Training  
March 25<sup>th</sup> 2004

# What is ACNET ?

- Accelerator Network
  - AcNet includes hardware, software, protocol for exchanging information,....
- Developed by the FNAL Controls Group
- Monitor and control devices throughout the accelerator and experimental areas
  - Beam currents
  - Luminosity
  - Losses
  - Over 100,000 devices total !
- Records historical information in “dataloggers”

- ACNET control/monitoring software runs on VAXes (VMS) and can create a virtual display console on machines running X-Windows. The VAXes are called consoles. CDF uses Windows 2000 PCs for the display machines.
- If interface seems unusual, it might have to do with the fact that ACNET was developed in the early 1980's to run on PDP-11's (and later on micro-Vaxes).
- There is an ACNET display PC in first floor counting room if you want to practice alone. Do NOT experiment outside of CDF procedures. It is possible to turn off the Tevatron from ACNET.
- But the best way to learn is hands-on practice with old ACE or other expert (like Steve Hahn!) looking over your shoulder.
- Our ACNET display PCs are physically connected to a Beams Division network. (and speaking of networks...)

# FERMILAB ACCELERATOR CONTROL SYSTEM


## CONSOLES

**PUBLIC**  
66 - VAXstation, NCD  
  
14 - MULTI-SCREEN  
43 - SINGLE-SCREEN  
9 - COMFORT DISPLAY


**PRIVATE**  
81 - VAXstation  
NCD, SUN, MAC  
  
49 - PRIVATE ASSIGNED  
32 - POOLED FOR 76 USERS

**SUMMARY**  
147 - CONSOLE INSTANCES  
49 - NODES  
  
17 - 4000/60    32 - 4000/60

## SERVERS



## FRONT ENDS



# Starting ACNET

- ACNET display runs on PCs on the West side of the Control Room
  - racks 2RR03G and 2RR05B – and in 1<sup>st</sup> floor counting room.
- Should already be running.
- **Automatically starts after reboot** (one way to recover from a problem). (Be patient – it takes a few minutes.)
- If it crashes or is unresponsive, do this to get it going again:
  - **START**
    - Programs
    - Acnet
    - Cnsrun

# Navigating in ACNET

- You will type wherever the cursor is.
- Move the cursor over the character where you want to type.
- Left mouse button works like “return” (text changes color).
- On index page, either click on the page number, or type in Top Left Corner.
- To get back to the index page, type letter of desired index page in the Top Left Corner.

## Many Index Pages

**B** – Booster

**C** – Collider

**D** – Diagnostic/Utility

**E** – Experimental

**I** – Main Injector

**L** – Linac

**P** – PBar

**R** – Recycler

**T** – Tevatron

# Some Useful and Essential Pages

- C65 Collider Luminosity
- D44 Lumberjack Plotter – plot stored data
- E8 Downtime Data Logger
- E11 E-Z Writer – livetime plots
- E2 SVX Loss Monitor
- E6 Silicon Radiation Monitoring
- E7 Monitor Store

# WHAT YOU NEED TO LEARN

- How to make real-time plots using E-Z writer E11
- How to make plots of historical data using the Lumberjack data logger page D44
- How to paste plots in the eLog
- How to record SVRAD totals at beginning of store
- How to make a BLM summary plot after a beam incident.
- How to use the Downtime Logger E8
  - For categorizing auto-entries
  - For making a “Store” entry

Make sure “old” ACEs teach you these items. (This talk only includes 2 slides on Downtime Logger.)



# Page E8 - CDF Downtime data Logger

- When data-taking stops for more than 2 minutes, an entry is generated automatically.
- Shift crew must edit to categorize downtime (HV, DAQ, Trigger, Level3, etc etc)
- VERY important to categorize downtime according to the underlying cause. (Just because the DAQ system stops taking data doesn't mean DAQ is the cause.)
- VERY important to do this on your shift while you have a good memory of the problems that led to downtime. Involve the SciCo is necessary.
- Allows for downtime accounting later

When a new store goes in, enter as COMMENT.  
Not an auto entry, so use ADD ENTRY

F8 Downtime Log Entry And Edit. Pgm Tools

Command Auto Entry Statistics Plot Manager Functions

Save Now Pend New Entry Quit

down:15-JAN-2002 1619 up:dd-mm-yy hhmm Downtime < >Name\_Help 1

Dn	Up	System Mode	Description of Problem
14-JAN-2002		Monday	
2214	2217	CMU HV H	PENDING
=>2222	225		Pick a group please...
2341	234	ACCELERATOR	
2346	235	DATA ACQUISITION	
15-J			COMMENTS
00	STORE		Store info. down = time at low beta. up = end store
00	STORCOM		Store comments.
00	STRSHFT		Start shift; crew list
01	ENDSHFT		End shift; Coop lump, CDF lump, downtime, beamtime
=>02	NOTES		notes for record
03			
0341	035	COMMENTS	
0424	042	TESTS	
0442	045		
0501	0505	HVCNTRL H	cmp cmx trip
0505	0511	HVCNTRL H	cmx trip
=>0613	0633	HVCNTRL H	cmp cmx trip

89:105 of 105

Messages

DOWN time is when scraping is complete ( $t_0$  for start of the store). Fill the UP time at the end of store. COMMENT should include store # and initial luminosity.

F8 Downtime Log Entry And Edit. Pgm Tools

Command Auto Entry Statistics Plot Manager Functions

Save Now Pend New Entry Quit

down:15-JAN-2002 1619 up:dd-mm-yyyy hhmm Downtime <STORE >Name\_Help 1

Store 999 - initial lum 1.5E31

Dn	Up	System Mode	Description of Problem
14-JAN-2002 Monday			
2214	2217	CMU HV H	PENDING
=>2222	2255	NOCATEG H	
2341	2345	CMU HV H	
2346	2356	TRIGLVL2 H L2 Done	timeout
15-JAN-2002 Tuesday			
0012	0018	HVCNTRL H	cmp,cmx trip
0025	0029	HVCNTRL H	CMX, CMP trips
0031	0050	HVCNTRL H	CMX, CMP trips due to high losses
0103	0120	STARTUP H	starting new run
=>0237	0259	STARTUP H	starting new run in order to include muon
0319	0330	HVCNTRL H	CMP CMX trip
0341	0351	STARTUP H	starting new run in order to include silicon
0424	0429	HVCNTRL H	cmx cmp trip
0442	0452	STARTUP H	new run startup
0501	0505	HVCNTRL H	cmp cmx trip
0505	0511	HVCNTRL H	cmx trip
=>0613	0633	HVCNTRL H	cmp cmx trip

89:105 of 105 Messages

# ACNET resources

Refer to links under “ACNET-Beam” on the Monitoring Ace  
“IFIX/Detector info/Recovery” page..


<http://www-cdfonline.fnal.gov/mcs/mondoc.html> .

The above pages may not be completely up-to-date but are  
certainly worth reading if you have slow time during a shift.

Shift crew resources:

- Bug your overlap ACE buddy, operations manager, JJ, and Steve Hahn !

# SHOT SETUP



Debuncher & Accumulator

Accelerator	Energy
Cockroft Walton	750 keV
Linac	400 MeV
Booster	8 GeV
Main injector	150 GeV
TEVATRON	980 GeV

Ron Moore will be giving a talk on the accelerator complex during upcoming Tuesday morning Ace Meeting.

# Shot Setup Terminology

- **Stacking** – Production and collection of antiprotons into the Accumulator. This operation can take place independent of the Tevatron.
- **Shot Setup** – the sequence of events leading to antiproton shots. Typically takes about 2 hours. Ideally would take much less.
- **Shot** – the injection of antiprotons from the Accumulator into the Main Injector and on into the Tevatron in preparation for colliding beams operation.
- **Store** – when there is a steady  $p$ ,  $pbar$  beam present in the Tevatron
  - Numbered sequentially
  - Typically lasts 12-36 hours
  - Can sometimes end abruptly
- In the best of times, CDF takes data continually with a 1-2 hour break once a day to end a store, take some calibrations, and start the next store.

# Shot setup checklist

- **Shot Setup Checklist** is **comprehensive** set of instructions to follow in preparation for a shot and data taking.
- **Special Instructions** – Always check the “White Board” for exceptions and special instructions to follow.
- Current version of checklist is linked from DAQ Ace help page. Please tell Ops Manager about anything that is confusing in the checklist or anything that needs updating.
- **Shot Setup Flowchart** helps DAQ Ace minimize lost beam time during startup. (not currently up-to-date or heavily used)

# Shot setup checklist

Please print out at least one copy at beginning of every shot setup.

## CDF Shot Setup Checklist

NOT CURRENT VERSION

date\_\_\_\_\_ Store#\_\_\_\_\_

[http://www-cdfonline.fnal.gov/opshelp/ShotSetupChecklist\\_v28.html](http://www-cdfonline.fnal.gov/opshelp/ShotSetupChecklist_v28.html)  
Revised 16 June-2003

### Instructions:

- Use this checklist during shot setup. File completed this form in a Shot Setup folder.
- Record entries in the shift elog.
- Recording times in the boxes is useful when communicating information during shift changes.

**1) Before a store (Many steps can be performed simultaneously.)**

Etc...




## shotsetup flow chart (with Silicon)

**OUT OF DATE**

- \* when antiproton loading starts, page silicon (218-8227)
- \* should be running AAA\_SHOTSETUP run.

**DPS (dynamic prescale) should be ENABLED for all physics runs.**

**Auto HRR should be ENABLED for all physics runs from the Error Handler GUI.**



Last update: Dec. 13 2002. Kaori

# Store Finale

- At the end of a store:
  - The Main Control Room (MCR) should notify CDF in advance of planned beam dumps.
  - End data taking run
  - Before the store is dumped, ramp down high voltage (allow 5 minutes)
  - SciCo notifies MCR that CDF is ready for store to be terminated.
- For stores that end abnormally with a beam incident:
  - *Usually* what is done is done. If beam is **gone**, most damage is done and you do not have to react instantaneously to problems.
  - Make sure you follow silicon “post quench checkout procedures”  
<http://www-cdfonline.fnal.gov/~svxii/runii/quench.html> .

# MUTTS



Like to sing or play an instrument – even if you can not? Talk to Steve about the CDF band – DSDI I.

**CDF RUN TOO!**

Like to run even if you can not? Talk to JJ about the CDF “running club” RUN TOO!